




8K 10" 8K LCD screen for freePRINT - LCD Replacement Manual



Step 1

Unscrew the 4 screws at the 4 corners of the LCD screen with a 2mm Allen key



Step 2

Lift the frame with the LCD screen paying attention to the cable on the back.




Step 3

Remove the highlighted piece of tape and keep it aside for later use.



Step 4

Raise the lever that holds the cable in place



Step 5

Remove the cable. ATTENTION: hold the cable so that it does not fall inside and pay attention to the direction of the connector, it has only one direction that allows you to connect it to the screen.



Step 6

Now it will be sufficient to repeat all the previous steps going back to connect the new LCD screen.